

FIG. 1




FIG. 2




FIG. 3

FIG. 3




FIG. 4

● SYSTEM SETTING

- EXTERNAL MONITOR SETTING
- TV OUTPUT SETTING
- LUMINANCE ADJUSTING
- LOW-TONE EMPHASIZING SETTING
- SILENT SETTING
- VOLUME SETTING
- RECORDING SETTING
- CAMERA SETTING
- OTHER SETTING
 - VOLUME SETTING FOR START TIME
 - DRIVING DEVICE SETTING
 - POWER-ON SYSTEM SETTING
 - SYSTEM SETTING
 - OPERATING DIAL SETTING

● CONVENIENT TOOL

- ACTIVE WINDOW SWITCHING
- DIAL-UP TOOL
- FOLDER BROWSER
- START MENU

● CLOSE FRONT WINDOW

● SYSTEM SUSPEND

● SYSTEM HYPER-NATION

● END

FIG. 5




FIG. 6




FIG. 7A




FIG. 7B




FIG. 7C




FIG. 7D




FIG. 8